



**For JBS Units without On-board Door Lock Relays:**

Requires  
 (1) 778 or  
 (2) 775's  
 (1) 480 OHM Resistor



**For JBS Units with On-board Door Lock Relays:**  
 Requires (1) 480 OHM Resistor



NOTE: Connect the RED WITH BLACK STRIPE wire to ground.

**JBS KE-100, KE-150 and 1702**  
 Requires (1) 480 OHM Resistor

