



2001 Lexus Navigation System

Including Early Production 2002 SC 430

Quick Reference Guide

ADDITIONAL NAVIGATION FUNCTIONS

Point of Interest (POI): Allows you to enter and route to categories such as airports, ATMs gas stations, golf courses, hotels, restaurants, and Lexus dealers.

Marked Point: Allows you to mark up to 100 of your favorite places or destinations including street addresses and phone numbers. You can retrieve these points by touching "Marked Points" on the "Destination" screen.

Previous Destination: Allows you to select one of your ten most recent destinations, saving you time by not having to enter the address again.

To view the demo mode, touch and hold **Start** for 10 seconds. The system will beep to indicate that the demo mode has begun.



To end the demo mode, press **MAP** on the navigation system face plate.




SPEECH COMMANDS (FOR THE LS 430 ONLY)

To activate the speech command option of the Lexus LS 430 Navigation System, press the speech command switch on the steering wheel command module. After you hear a beep, say one of the speech commands listed below. For some speech commands that affect the route guidance, the navigation system will confirm your command by asking, "Are you sure you want to...?" and will repeat the command. Press the speech command switch and reply yes or no.

For a complete list of possible speech commands, please consult the Lexus Navigation System Owner's Manual.

MAP OPERATION	DESTINATION FROM LIST	REPLY	POI DISPLAY ON MAP
Current position Zoom in, Zoom out Minimum scale, Maximum scale Change to north up Change to heading up Mark (to register a point)	*Go to marked point *Go to previous destination *Number one *Number two *Number three *Number four *Number five	Yes No	Airport ATM Automobile club Bank Gas station Grocery store Hospital Lexus dealership Parking garage/Parking lot Police station Rest area Restaurant (American Continental, French, Japanese, Mexican) POI off
GUIDANCE MODE CHANGE	ROUTE CHANGE	GUIDANCE HELP	
Change to arrow guidance Change to turn list guidance Change to single screen Change to split screen	*Cancel guidance *Reroute *Detour *Alternate roads *Delete (next, first, second, third, fourth, fifth, final) waypoint	Repeat guidance Show route Show destination Show (next, first, second, third, fourth, fifth, final) waypoint	
DESTINATION		VOLUME	
*Go home *Go to starting point		Louder Softer Voice guidance off Voice guidance on	

*Speech commands that require confirmation.

To access the Emergency screen, press **DEST** or **DESTINATION** on the navigation system face plate. Then touch 



The emergency screen will appear and offer several choices.



SAFETY INSTRUCTIONS

This system is intended to assist you in reaching your destination and, if used properly, can do so. To use your system as safely as possible, follow all safety instructions.

YOU, AS THE DRIVER, ARE SOLELY RESPONSIBLE FOR THE SAFE OPERATION OF YOUR VEHICLE AND THE SAFETY OF YOUR PASSENGERS. DO NOT USE ANY FEATURE OF THIS SYSTEM TO THE EXTENT IT DISTRACTS YOU FROM SAFE DRIVING. YOUR FIRST PRIORITY WHILE DRIVING SHOULD ALWAYS BE THE SAFE OPERATION OF YOUR VEHICLE.

- Before attempting to use this system while driving, learn how to use it. Read the entire Navigation System Manual to make sure you understand the system. Do not allow others to use this system until they have read and understand these and other instructions in this manual.
- You can input your destination and select your route only when your vehicle is not moving. While driving, listen to the voice instructions as much as possible and glance at the screen briefly and only when safe.
- The data in the system may occasionally be incomplete. Road conditions, including driving restrictions (no left turns, street closures, etc.) frequently change. Therefore, before you follow any instruction from the system, look to see whether you can comply with the instruction safely and legally.
- This system cannot warn you about such things as the quality of a neighborhood, street conditions, and availability of emergency services. If you are unsure about the safety of an area, don't drive into it.

UNDER NO CIRCUMSTANCES IS THIS SYSTEM A SUBSTITUTE FOR THE DRIVER'S PERSONAL JUDGMENT

- We recommend that you obtain updated data as it becomes available in order to help use the system as effectively and safely as possible.
- Use this system only in locations where it is legal to do so. Some states/provinces may have laws prohibiting video screens within sight of the driver.

For additional information, please refer to the Lexus Navigation System Owner's Manual or call Lexus Customer Satisfaction at (800) 25-LEXUS (255-3987).

Lexus Navigation System Face Plate

LS 430 shown. Button positions may vary among models.

NORTH-UP AND MAP SCALE Symbol

This symbol indicates a map view with North-up. Press this symbol to change the map view to a head-up perspective. This symbol also indicates the map scale.

GLOBAL POSITIONING SYSTEM (GPS) Mark

This mark is displayed whenever the GPS receiver within the navigation ECU is tracking the vehicle position.

MAP/GUIDE Symbol

Touch this symbol to change the screen mode.

CURRENT VEHICLE POSITION Mark

This mark indicates the current position of the vehicle.



MAP/VOICE Button
Push this button to repeat a Guidance voice, cancel the one touch scroll and start a Guidance.


DESTINATION Button
Push this button to display the DESTINATION screen.

OPTION Button
Push this button to display the MENU screen. This screen allows you to make adjustments or to correct settings of various options and functions.

ZOOM IN/ZOOM OUT Buttons
These symbols magnify or reduce the map scale.

DESTINATION INPUT

step 1



Read the CAUTION screen and touch **I agree**.

step 2



The map screen appears. Press **zoom** or **mark** on the navigation system face plate.

step 3



To access the address input screen, touch **Address**.

step 4



Touch **House No.** and type in the street address number.

step 5



Touch **Street** to input the street name and then touch **List**.

step 6



Use the arrows to scroll up and down. Then select desired street by touching **Enter**.

step 7



Select desired route or touch **Enter** and the system will begin searching the route.

step 8



Begin driving.


POINT OF INTEREST INPUT

step 1



Read the CAUTION screen and touch **I agree**.

step 2



Press **DEST** or **point of interest** on the navigation system face plate. To access the POI screen, touch **Point of Interest**.

step 3



Touch **Name** to type in the POI name or touch **Category** to view POI categories.

step 4



Input the POI name using the letter keys and touch **List**.

step 5



Use the arrows to scroll up and down. Then select desired location by **touching**.

step 6



Select desired route preference or touch **Enter**.

step 7



The system will begin searching the route.

step 8



Begin driving.