

<p>① : Engine Room No.1 R/B</p> <p>② : Engine Room No.2 R/B</p>	<h2 style="margin: 0;">Engine Compartment Left (See Page 8)</h2>
---	--

[RHD]

*1:15A H-LP L LWR
 *2:15A H-LP R LWR

