


DISASSEMBLY

- 1. REMOVE A/C AMPLIFIER
- (a) Remove the 4 screws.




(b) Using a screwdriver, release the 4 claws and pull out the A/C amplifier.

AC264-01


HINT:

Tape the screwdriver tip before use.




(c) Release the connector lock and pull out the flat harness. **NOTICE:**

Pull the lock of the connector securely toward you and pull off the flexible flat cable.




2. REMOVE BULBS

Using a screwdriver, turn the bulbs to the left and pull out the bulbs.






Remove the 4 screws and P/C board.



NOTICE:


•

- Do not let any oil, dirt or foreign object on the connecting part of the P/C board.
- When holding the P/C board by hand, hold it at the edge and do not touch the soldered part and connecting part.
- Do not apply unnecessary force to the jumper lead.
- Do not let the accumulated static electricity in an operator apply to the electronic components.
- Do not tumble the LED as this soldered to the P/C board at right angles.




4. REMOVE DIAL KNOBS

Remove the 6 screws and dial knobs.




NOTICE:

- Do not let any oil, dirt or foreign object attach on the connecting part of the connector.
- Do not deform the contact.
- Be careful not to drop the contact.



5. REMOVE KNOB SETS

Pull out the knob sets.



NOTICE: Do not let any oil, dirt or foreign object attach on the rubber contact part.

6. REMOVE LENS

