







CLIP REPLACEMENT

BO0VU-06







The removal and installation methods of typical clips used in body parts are shown in the table below.

HINT:

If the clip is damaged during the operation, always replace it with a new clip.

Shape (Example)	Removal/Installation
	
	
	

V00005

Shape (Example)	Removal/Installation	
	<p data-bbox="837 302 949 331">Removal</p> 	<p data-bbox="1165 302 1300 331">Installation</p> 
	<p data-bbox="861 795 973 824">Removal</p> 	<p data-bbox="1204 795 1332 824">Installation</p> 

V00012