

INSTALLATION

Installation is in the reverse order of removal (See page BR-12).

HINT:

- Before installation, adjust length of brake booster push rod (See page BR-21).
- After installation, fill the brake reservoir with brake fluid, bleed brake system (See page BR-4), and check for leaks.
- Check and adjust brake pedal (See page BR-6).