BR0JV-04

REASSEMBLY

Reassembly is in the reverse order of disassembly (See page BR-36).

HINT:

Apply lithium soap base glycol grease to the parts indicated by the arrows (See page BR-34).