

INSTALLATION

Installation is in the reverse order of removal (See page BR-35).

HINT:

- After installation, fill the brake reservoir with brake fluid and bleed brake system (See page BR-4).
- Check for leaks.