



## INSTALLATION

### 1. INSTALL ELECTRIC COOLING FAN

- (a) Install the electric cooling fan with the 6 bolts.  
**Torque: 5.0 N·m (50 kgf·cm, 44 in·lbf)**
- (b) Connect the radiator reservoir hose to the radiator.
- (c) Connect the wire for the electric cooling fan to the clamps on the electric cooling fan.
- (d) Connect the 2 electric cooling fan connectors.
- (e) Connect the engine ECU outlet duct to the fan shroud.
- (f) Connect the upper radiator hose to the radiator.

### 2. INSTALL AIR CLEANER INLET

### 3. FILL WITH ENGINE COOLANT

### 4. INSTALL NO.1 ENGINE UNDER COVER

### 5. START ENGINE AND CHECK FOR COOLANT LEAK