

# ABS & TRACTION CONTROL SYSTEM

## HOW TO PROCEED WITH TROUBLESHOOTING

DI08V-05

Troubleshoot in accordance with the procedure on the following pages.

