



PARTS LOCATION



Engine and ECT ECU



Driver Side Junction Block
● IGN Fuse

Transponder Key Amplifier

Transponder Key Coil

P

I10857