

# FUEL TANK AND LINE

## COMPONENTS

FI026-02

### CAUTION:

- Always use new gasket when replacing the fuel tank or component parts.
- Apply proper torque to all parts tightened.

