



BRAKE INSPECTION

MA01R-03

1. INSPECT BRAKE PEDAL AND PARKING BRAKE (See pages BR-6 and BR-42)

2. INSPECT BRAKE LINE PIPES AND HOSES

HINT:

Check in a well lighted area. Check the entire circumference and length of the brake hoses using a mirror as required. Turn the front wheels fully right or left before checking the front brake.

(a) Check all brake lines and hoses for.

- Damage
- Wear
- Deformation
- Cracks
- Corrosion
- Leaks
- Bends
- Twists

(b) Check all clamps for tightness and connections for leakage.

(c) Check that the hoses and lines are clear of sharp edges, moving parts and the exhaust system.

(d) Check that the lines install in grommets pass through the center of the grommets.

3. INSPECT FRONT AND REAR BRAKE PADS AND DISCS

(FRONT PADS: See page BR-23)

(REAR PADS: See page BR-32)

(FRONT DISCS: See page BR-28)

(REAR DISCS: See page BR-37)

4. INSPECT PARKING BRAKE LININGS AND DRUMS (See page BR-42)

5. INSPECT OR CHANGE BRAKE FLUID

(See page BR-4)

Fluid: SAE J1703 or FMVSS No.116 DOT3