



# MANUAL TRANSMISSION ASSEMBLY

## COMPONENTS

MT08W-01




D05996




◆ Non-reusable part

T

D06039



D06038



D06040