INSTALLATION

HINT:

For step 1 to 4, refer to page SR-23.

- 1. INSTALL SPIRAL CABLE
- 2. INSTALL STEERING COLUMN UPPER AND LOWER COVERS
- 3. INSTALL STEERING WHEEL
- 4. INSTALL STEERING WHEEL PAD

RS013-19