


IDENTIFICATION INFORMATION

VEHICLE IDENTIFICATION AND ENGINE SERIAL NUMBER


IN04P-04



1. VEHICLE IDENTIFICATION NUMBER

The vehicle identification number is stamped on the cowl panel. This number has also been stamped on the manufacturer's plate and the identification number plate (Europe RHD), as shown in the illustration.

- A: Manufacturer's Plate
- B: Vehicle Identification Number
- C: Identification Number Plate (Europe RHD)



2. ENGINE SERIAL NUMBER

The engine serial number is stamped on the engine block, as shown in the illustration.