



## INSTALLATION

### 1. INSTALL COOLING FAN

- (a) Install the cooling fan with the 6 bolts.  
**Torque: 5.0 N·m (50 kgf·cm, 44 in·lbf)**
- (b) Connect the upper radiator hose to the radiator.
- (c) Connect the ECU outlet duct to the ECU box.
- (d) Connect the wire for cooling fan to clamp on the cooling fan.
- (e) Connect the 2 cooling fan connectors.
- (f) Connect the radiator reservoir hose to the radiator.

### 2. INSTALL AIR CLEANER AND MAF METER ASSEMBLY

### 3. INSTALL AIR CLEANER INLET

### 4. FILL WITH ENGINE COOLANT

### 5. START ENGINE AND CHECK FOR COOLANT LEAKS