



FRONT WIPER AND WASHER INSPECTION

BO4CU-01

INSPECT WASHER NOZZLE

- (a) While operating the washer. Check whether the upper point where the washer fluid hits the windshield and the surge area are within the range indicated by the hatched line.

A: Approx. 150 mm (5.91 in.)

B: Approx. 50 mm (1.97 in.)

C: Approx. 50 mm (1.97 in.) (Australia models only)

D: Approx. 50 mm (1.97 in.) (Except Australia models)

E: Approx. 320 mm (12.60 in.)

F: Approx. 181 mm (7.13 in.)

G: Approx. 120 mm (4.72 in.)

H: Approx. 546 mm (21.50 in.)

I: Approx. 447 mm (17.60 in.)

J: Approx. 443 mm (17.45 in.)

K: Approx. 117 mm (4.61 in.)

L: Approx. 176 mm (6.93 in.)

M: Approx. 320 mm (12.60 in.)

N: Approx. 181 mm (7.13 in.)

- (b) Check if the lower point where the washer fluid hits the windshield is within the range of the wiping pattern (the area of the glass which is wiped by the wiper blades).