



REMOVAL

REMOVE ROOF DRIP SIDE FINISH MOULDING CENTER

- (a) Tape the circumference of the moulding for protection.
- (b) Using a remover for the roof moulding, release the engagements of the clips both in the front and rear ends of the moulding, and then remove the roof drip side finish moulding.

NOTICE:

- **Do not remove the clips.**
- **In case that the clips are damaged or removed accidentally, exchange them into supplied ones.**