

## INSTALLATION

Installation is in the reverse order of removal (See page BR-25).

HINT:

- After installation, fill the brake reservoir with brake fluid, bleed brake system (See page BR-1).
- Check for leaks.