



INSTALLATION

1. **INSTALL ELECTRIC COOLING FAN**
 - (a) Install the electric cooling fan with the 6 bolts.
Torque: 5.0 N·m (50 kgf·cm, 44 in·lbf)
 - (b) Connect the upper radiator hose to the radiator.
 - (c) Connect the ECU outlet duct to the ECU box.
 - (d) Connect the wire for electric cooling fan to clamp on the electric cooling fan.
 - (e) Connect the 2 electric cooling fan connectors.
 - (f) Connect the radiator reservoir hose to the radiator.
2. **INSTALL AIR CLEANER AND AIR FLOW METER ASSEMBLY**
3. **INSTALL AIR CLEANER INLET**
4. **FILL WITH ENGINE COOLANT**
5. **START ENGINE AND CHECK FOR COOLANT LEAKS**