## **AUTOMATIC TRANSMISSION (A650E)**HOW TO PROCEED WITH TROUBLESHOOTING

DIE1K O

When using hand-held tester, troubleshoot in accordance with the procedure on the following pages. Items inside \( \bigcup \) are titles of pages in this manual, with the Vehicle Brought to Workshop page number indicated in the bottom portion. See the indicated pages for detailed explanations. Customer Problem Analysis P. DI-169 Connect the hand-held tester or OBD scan tool to DLC3. If the display shows "UNABLE TO CONNECT TO VEHICLE" when you have connected the OBD scan tool/hand-held tester, inspect DLC3 P. DI-170 Check DTC and Freeze Frame Data (Precheck) Record or Print DTC and Freeze Frame Data P. DI-170 4 // Clear DTC and Freeze Frame Data P. DI-170 5// Visual Inspection // 6 / Setting the Check Mode Diagnosis P. DI-170 Symptom does not occur Symptom Simulation 7 Problem Symptom Confirmation P. IN-23 Symptom occurs DTC Check Basic Inspection // NG P. DI-170 P. DI-170 OK 10 DTC Chart 12 Mechanical System Test P. DI-170 OK NG 13 Manual Shifting Test P. DI-170 14 Problem Symptoms Table-P. DI-190 NG Chapter 1 Chapter 2 Chapter 3 OK OK (Electronic) (Off-Vehicle) (On-Vehicle) P. DI-190 P. DI-190 NG NG 16 // Parts Inspection / Pattern Select Switch Signal Circuit Check Circuit • Kick-down Switch Circuit Check Inspection P. DI-237 to DI-247 Repair Confirmation Test Identification of Problem

When not using hand-held tester, troubleshoot in accordance with the procedure on the following pages.

