


# SUPPLEMENTAL RESTRAINT SYSTEM

## HOW TO PROCEED WITH TROUBLESHOOTING

DI422-05



Step 3, 4, 6, 8, 9, 11 : Diagnostic steps permitting the use of the hand-held tester.