

**EQUIPMENT**

Clip remover	
Torque wrench	
Torx driver	
Hog ring pliers	
Hand riveter	
Tape	To avoid surface damage
Adhesive tape	To avoid surface damage
Adhesive	
Cleaner	
Shop rag	
Knife	
Sealer gun	
Brush	
Wooden block or similar object	For tying both piano wire ends
Plastic sheet	To avoid surface damage