

AXLE SYSTEM

PROBLEM SYMPTOMS TABLE

Use the table below to help determine the cause of the problem. The numbers indicate the priority of the possible cause of the problem. Check each part in order. If necessary, replace these parts.

AXLE SYSTEM

Symptom	Suspected area	See page
Wander	1. Wheel alignment (Front)	SP-2
	2. Wheel alignment (Rear)	SP-7
	3. Steering linkage (Loosen or worn)	-
	4. Front hub bearing	AH-5
	5. Rear hub bearing (2WD)	AH-15
	6. Rear hub bearing (4WD)	AH-18
	7. Stabilizer bar (Front [2WD])	SP-28
	8. Stabilizer bar (Front [4WD])	SP-28
	9. Stabilizer bar (Rear [2WD])	SP-67
	10. Stabilizer bar (Rear [4WD])	SP-70
Front wheel shimmy	1. Wheel balance	TW-1
	2. Shock absorber (Front)	SP-11
	3. Shock absorber (Rear)	SP-38
	4. Pneumatic rear LH w/shock absorber cylinder assembly	SP-44
	5. Ball joint (Worn)	SP-24
	6. Hub bearing (Worn)	AH-5