

SYSTEM DESCRIPTION

1. KEY REMINDER WARNING SYSTEM DESCRIPTION

- (a) When the driver side door is opened with the ignition key in the ACC or LOCK position, this system causes a buzzer to sound in order to warn the driver that the ignition key has not been removed.

HOW TO PROCEED WITH TROUBLESHOOTING

HINT:

- Use these procedures to troubleshoot the key reminder warning system.
- The intelligent tester should be used in steps 3 and 5.

1 VEHICLE BROUGHT TO WORKSHOP

NEXT

2 CUSTOMER PROBLEM ANALYSIS

- (a) Interview the customer to confirm the trouble (See page [IN-36](#)).

NEXT

3 INSPECT COMMUNICATION FUNCTION OF MULTIPLEX COMMUNICATION SYSTEM (BEAN)

- (a) Use the intelligent tester to check if the Multiplex Communication System (MPX) is functioning normally.

Result

Result	Proceed to
MPX DTC is not output	A
MPX DTC is output	B

B

GO TO MULTIPLEX COMMUNICATION SYSTEM

A

4 PROBLEM SYMPTOMS TABLE

Result

Result	Proceed to
Fault is not listed on problem symptoms table	A
Fault is listed on problem symptoms table	B

B

After repair, go to step 7

A

5 OVERALL ANALYSIS AND TROUBLESHOOTING

- (a) Terminals of ECU
(See page [DL-104](#))
- (b) DATA LIST/ACTIVE TEST

DL

(See page [DL-106](#))

NEXT

6	REPAIR OR REPLACE
---	-------------------

NEXT

7	CONFIRMATION TEST
---	-------------------

NEXT

END
