CUSTOMIZE PARAMETERS

HINT:

The following items can be customized.

NOTICE:

- When the customer requests a change in a function, first make sure that customization of the function(s) is possible.
- Be sure to record the current settings before customizing.
- When troubleshooting a function, first make sure that the function is not set to OFF.

| Display (Item) | Default | Contents | Setting |
|--|---------|---|-------------|
| OPEN DOOR WARN (Open door warning) | ON | If a door is not completely closed and LOCK is pressed, this function sounds a buzzer for 10 seconds. | ON / OFF |
| WIRLS BUZZ RESP (Buzzer answer-back of Wireless) | ON | This function makes the wireless door lock buzzer sound for answer-back when LOCK/UNLOCK is pressed. | ON / OFF |
| WIRELESS OPER (Wireless door lock control function) | ON | This function turns the wireless door lock function on or off. | ON / OFF |
| ALARM FUNCTION (Panic function) | ON | This function operates the theft deterrent system when PANIC is pressed and held for 0.8 (*1) or 2.5 (*2) seconds. | ON / OFF |
| UNLOCK/2OPER (Wireless unlock operated twice) | ON | This function unlocks the driver side door when UNLOCK is pressed once, and unlocks all doors when pressed twice. If set to OFF, pressing UNLOCK once unlocks all doors. | ON / OFF |
| AUTO LOCK DELAY (Auto lock time) | 30 s | This function controls the amount of time from unlocking doors to automatic re-locking. | 30 s / 60 s |
| HAZARD ANS BACK (Hazards answer-back for wireless door lock operation) | ON | When LOCK is pressed, all hazard warning lights flash once. When UNLOCK is pressed, all hazard warning lights flash twice. | ON / OFF |

HINT:

• (*1): w/ Power Back Door

• (*2): w/o Power Back Door



PROBLEM SYMPTOMS TABLE

HINT:

Inspect the fuse and relay before investigating the suspected areas shown in the table below.

WIRELESS DOOR LOCK CONTROL SYSTEM:

| Symptom | Suspected area | See page |
|---|-------------------------------|----------|
| Only wireless control function is inoperative | 1. Transmitter battery | DL-84 |
| | 2. Door control transmitter | DL-84 |
| | 3. Door control receiver | DL-84 |
| | 4. Unlock warning switch | DL-84 |
| | 5. Wire harness | DL-84 |
| | 6. Multiplex network body ECU | DL-84 |
| | 7. Instrument panel J/B | DL-84 |
| | Wireless door lock buzzer | DL-93 |
| No answer-back (Hazard warning light and wireless door lock buzzer) | 2. Lighting system | DL-93 |
| | 3. Wire harness | DL-93 |
| | 4. Multiplex network body ECU | DL-93 |

