


# BACK DOOR SUPPORT

## COMPONENTS



## REMOVAL

### 1. REMOVE BACK DOOR SUPPORT

#### NOTICE:

**While holding the back door, remove the back door stay assembly.**

- (a) Remove the 4 bolts and back door support.

