

INSTALLATION

1. INSTALL BACK DOOR SUPPORT

- (a) Install the back door support with the 4 bolts.
Torque: 8.0 N*m (82 kgf*cm, 71 in.*lbf)

DISPOSAL

1. DISPOSE OF BACK DOOR SUPPORT

- (a) Horizontally fix the stay in a vise with the piston-rod pulled out.
- (b) Wear safety glasses. Gradually cut a part between A and B shown in the illustration using a metal saw and gradually release the gas.

NOTICE:

Although the gas inside the stay is colorless, odorless and harmless, there is a possibility that metal debris could scatter. Therefore, cover it with clothes or equivalent..

