

## POWER BACK DOOR SYSTEM

### PRECAUTION

**NOTICE:**

When disconnecting the cable from the negative (-) battery terminal, initialize the following system after the cable is reconnected.

System	See procedure
Lighting System	<a href="#">LI-17</a>
Sliding Roof System	<a href="#">RF-4</a> and <a href="#">RF-22</a>
Power Window Control System	<a href="#">WS-12</a>
Power Back Door System	<a href="#">ED-6</a>

# PARTS LOCATION

