

# ELECTRICAL BACK DOOR OUTSIDE HANDLE SYSTEM


## PRECAUTION

### NOTICE:

When disconnecting the cable from the negative (-) battery terminal, initialize the following system after the cable is reconnected.

| System                      | See procedure                                  |
|-----------------------------|--|
| Lighting System             | <a href="#">LI-17</a>                          |
| Sliding Roof System         | <a href="#">RF-22</a> and <a href="#">RF-4</a> |
| Power Window Control System | <a href="#">WS-12</a>                          |
| Power Back Door System      | <a href="#">ED-33</a>                          |

# PARTS LOCATION



**ED**