



FUEL INJECTOR

COMPONENTS


FU





N*m (kgf*cm, ft.*lbf) : Specified torque



FU



N*m (kgf*cm, ft.*lbf) : Specified torque

● Non-reusable part

Y



N*m (kgf*cm, ft.*lbf) : Specified torque

● Non-reusable part

Y