



BACK-UP LIGHT ASSEMBLY



COMPONENTS



BACK DOOR TRIM PANEL ASSEMBLY UPPER





BACK-UP LIGHT ASSEMBLY



REMOVAL

1. **REMOVE BACK DOOR TRIM PANEL ASSEMBLY UPPER**
2. **REMOVE BACK-UP LIGHT ASSEMBLY**
 - (a) Disconnect each connector.
 - (b) Remove the 3 nuts and disengage the clip, and remove the back-up light assembly.



DISASSEMBLY

1. **REMOVE BACK-UP LIGHT BULB**
 - (a) Turn in the direction indicated by the arrow and remove the back-up light bulb and No.2 socket plug as a unit.
2. **REMOVE NO.2 SOCKET PLUG**
 - (a) Remove the back-up light bulb from the No.2 socket plug.