
DISASSEMBLY

1. **REMOVE REFLEX REFLECTOR BULB**
 - (a) Remove the reflex reflector bulb, the reflex reflector LH socket plug.
 - (b) Remove the reflex reflector bulb from the reflex reflector LH socket plug.
2. **REMOVE REFLEX REFLECTOR LH SOCKET PLUG**
3. **REMOVE REFLEX REFLECTOR LENS REAR LH**

REASSEMBLY

1. **INSTALL REFLEX REFLECTOR LENS REAR LH**
2. **INSTALL REFLEX REFLECTOR LH SOCKET PLUG**
3. **INSTALL REFLEX REFLECTOR BULB**

