

INSIDE HANDLE LIGHT

INSPECTION

1. INSPECT INSIDE HANDLE LIGHT

- (a) Remove the inside handle light.
- (b) Connect the battery positive (+) lead to terminal 2 and negative (-) lead to terminal 1.
- (c) Turn on the glove box light switch.
- (d) Check that the light comes on.

OK:

Comes on

If the light does not come on, replace the light.

