

# POWER MIRROR CONTROL SYSTEM (w/ Memory)

## PRECAUTION

### NOTICE:

When disconnecting the negative (-) battery cable, initialize the following systems after the cable is reconnected.

System Name	See Procedure
Lighting System (Adaptive Front-Lighting System)	<a href="#">LI-17</a>
Sliding Roof Control	<a href="#">RF-4</a> and <a href="#">RF-22</a>
Power Window Control System	<a href="#">WS-12</a>
Power Back Door System	<a href="#">ED-33</a>

# PARTS LOCATION

