


POWER MIRROR CONTROL SYSTEM (w/o Memory)

PARTS LOCATION



OUTER REAR VIEW MIRROR

OUTER REAR VIEW MIRROR

Instrument Panel J/B

- ECU-ACC fuse

OUTER MIRROR SWITCH

MI

PROBLEM SYMPTOMS TABLE**Power Mirror Control System**

| Symptom | Suspected area | See page |
|--|------------------------------------|-----------------------|
| Power mirror cannot be adjusted manually | 1. ECU-ACC fuse | - |
| | 2. Outer Mirror Switch | MI-38 |
| | 3. Outer Rear View Mirror Assembly | MI-33 |
| | 4. Wire harness | - |