


SYSTEM DIAGRAM



SYSTEM DESCRIPTION

The power mirror control system with memory function moves the power mirror to the memorized position when the seat memory switch is pressed. The system is controlled by the seat ECU (position control ECU & switch assembly built into the driver side seat) whose memory function records the desired position of the mirror and the outer mirror control ECU which commands the mirror motor to operate. When the power mirror control system with memory function is operating normally, pressing the seat memory switch activates the seat ECU to send a signal to the outer mirror control ECU via BEAN, which then commands the mirror to move the memorized position.