



FRONT POWER SEAT CONTROL SYSTEM (w/o Memory)

PARTS LOCATION



INSTRUMENT PANEL J/B ASSEMBLY

- IG1 RELAY
- ECU-IG NO. 1 FUSE
- P/SEAT M-FUSE



SE