

SLIDING ROOF SYSTEM (for Standard)

PRECAUTION

NOTICE:

When disconnecting the negative (-) battery terminal, initialize the following systems after the cable is reconnected.

System Name	See Procedure
Lighting System (Adaptive Front-Lighting System)	LI-17
Power Window Control System	WS-12
Power Back Door System	DL-8
Sliding Roof System	RF-22

PARTS LOCATION

