HOW TO PROCEED WITH TROUBLESHOOTING

The intelligent tester can be used at step 3, 6, 9 and 12.

1	VEHICLE BROUGHT TO WORKSHOP	
NEXT		
2	CUSTOMER PROBLEM ANALYSIS	
NEXT		
3	PROBLEM SYMPTOM CONFIRMATION	
	SYMPTOM DOES NOT OCCUR (Go to step 4)	
	SYMPTOM OCCURS (Go to step 5)	
4	SYMPTOM SIMULATION	
NEXT		
5	DTC CHECK	
	NORMAL CODE (Go to step 6)	
	MALFUNCTION CODE (Go to step 7)	
6	PROBLEM SYMPTOMS TABLE	
NEXT		
7	DTC CHECK	
NEXT		
8	CIRCUIT INSPECTION	
NEXT		

9	IDENTIFICATION OF PROBLEM	
NEXT		
10	REPAIR	
NEXT		
11	CONFIRMATION TEST	
NEST		
END		