

WINDOW DEFOGGER SYSTEM

PRECAUTION



1. INITIALIZATION

NOTICE:


When disconnecting the cable from the negative (-) battery terminal, initialize the following systems after the cable is reconnected.

System Name	See Procedure
Lighting System (Adaptive Front-Lighting system)	LI-17
Sliding Roof Control System	RF-22 and RF-4
Power Window Control System	WS-12
Power Back Door System	ED-33

PARTS LOCATION



WS



H

B112792E01