

# 1 HOW TO READ THE WIRING DIAGRAMS

MODELS ..... 1-2

## MODELS

<Vehicles for Europe>

### Hatchback

Model code		Engine model	Transmission model	Fuel supply system
CA1A	MNMEQL6	4G13 (1,299 mℓ)	F5M21 (2WD-5M/T)	MPI
	MNDEQL6/R6			
	MNJEQL6/R6			
CA4A	MNDEQL6	4G92 (1,597 mℓ)	F5M22 (2WD-5M/T)	
	MRDEQL6		F4A22 (2WD-4A/T)	
	MNJEQL6/R6		F5M22 (2WD-5M/T)	
	MRJEQL6/R6		F4A22 (2WD-4A/T)	
	MNJAQL6/R6		F5M22 (2WD-5M/T)	
CA5A	MNGMQL6/R6	4G93 (1,834 mℓ)	F5M22 (2WD-5M/T)	
CC4A	MNJEQL6	4G92 (1,597 mℓ)	W5M31 (4WD-5M/T)	

### Sedan

Model code		Engine model	Transmission model	Fuel supply system	
CB1A	SNMEQL6	4G13 (1,299 mℓ)	F5M21 (2WD-5M/T)	MPI	
	SNDEQL6/R6				
	SNJEQL6/R6				
CB4A	SNDEQL6	4G92 (1,597 mℓ)	F5M22 (2WD-5M/T)		
	SRDEQL6		F4A22 (2WD-4A/T)		
	SNJEQL6/R6		F5M22 (2WD-5M/T)		
	SRJEQL6/R6		F4A22 (2WD-4A/T)		
	SNJAQL6		F5M22 (2WD-5M/T)		
CB5A	SNGMQL6/R6	4G93 (1,834 mℓ)	F5M22 (2WD-5M/T)		
CB8A	SNDQL6	4D68 (1,998 mℓ)			
	SNJQL6				
	SNML6				
	SNDL6				
	SNJL6/R6				
				Diesel Fuel Injection	

**Wagon**

Model code		Engine model	Transmission model	Fuel supply system
CB4W	LNDEQL6	4G92 (1,597 ml)	F5M22 (2WD-5M/T)	MPI
	LNJEQL6/R6		F4A22 (2WD-4A/T)	
	LRJEQL6/R6			
CB8W	LNDQL6	4D68 (1,998 ml)	F5M22 (2WD-5M/T)	Diesel Fuel Injection
	LNJQL6			
	LNDL6			
	LNJL6/R6			
CD4W	LNDEQL6	4G92 (1,597 ml)	W5M31 (4WD-5M/T)	MPI
	LNJEQL6/R6			

**<Vehicles for General Export (except for Hong Kong)>**

**Hatchback**

Model code		Engine model	Transmission model	Fuel supply system
CA1A	MNDL/R	4G13 (1,299 ml)	F5M21 (2WD-5M/T)	Variable-venturi carburettor
CA2A	MNJL	4G15 (1,468 ml)	F5M21 (2WD-5M/T)	
	MKJL/R		F3A21 (2WD-3A/T)	
CA4A	MNJEQR	4G92 (1,597 ml)	F5M22 (2WD-5M/T)	MPI
	MRJEQR		F4A22 (2WD-4A/T)	

**2-door sedan**

Model code		Engine model	Transmission model	Fuel supply system
CA5A	DNDER	4G93 SOHC (1,834 ml)	F5M22 (2WD-5M/T)	MPI
	DRDER		F4A22 (2WD-4A/T)	

# 1-4

## HOW TO READ THE WIRING DIAGRAMS – Models

### 4-door sedan

Model code		Engine model	Transmission model	Fuel supply system
CB1A	SNML/R	4G13 (1,299 ml)	F5M21 (2WD-5M/T)	Variable-venturi carburettor
	SNDL/R		F3A21 (2WD-3A/T)	
	SKDL/R		F5M21 (2WD-5M/T)	
	SNJR		F3A21 (2WD-3A/T)	
	SKJR		F5M21 (2WD-5M/T)	MPI
	SNDEQR			
	SNJEQR			
CB2A	SNJL/R	4G15 (1,468 ml)	F5M21 (2WD-5M/T)	Variable-venturi carburettor
	SKJL/R		F3A21 (2WD-3A/T)	
CB3A	SNHMR1D	4G91 (1,496 ml)	F5M21 (2WD-5M/T)	MPI
	SRHMR1D		F4A21 (2WD-4A/T)	
CB4A	SNJEQR	4G92 (1,597 ml)	F5M22 (2WD-5M/T)	
	SRJEQR		F4A22 (2WD-4A/T)	
CB5A	SNGMQR	4G93 (1,834 ml)	F5M22 (2WD-5M/T)	
CB8A	SNDL/R	4D68 (1,998 ml)	F5M22 (2WD-5M/T)	
	SNAL/R <TAXI>			

### Wagon

Model code		Engine model	Transmission model	Fuel supply system
CB1W	LNML/R	4G13 (1,299 ml)	F5M21 (2WD-5M/T)	Variable-venturi carburettor
	LNDL/R		F3A21 (2WD-3A/T)	
	LKDL/R			
CB2W	LNJL/R	4G15 (1,468 ml)	F5M21 (2WD-5M/T)	Variable-venturi carburettor
	LKJL/R		F3A21 (2WD-3A/T)	
CB4W	LNJEQR	4G92 (1,597 ml)	F5M22 (2WD-5M/T)	MPI
	LRJEQR		F4A22 (2WD-4A/T)	

<Vehicles for General Export (Hong Kong)>

Sedan

Model code		Engine model	Transmission model	Fuel supply system
CB1A	SNJR1D	4G13 (1,299 ml)	F5M22 (2WD-5M/T)	Electronic control carburettor
	SKJR1D		F4A22 (2WD-4A/T)	
CB8A	SNAR1D <TAXI>	4D68 (1,998 ml)	F5M22 (2WD-5M/T)	Diesel Fuel Injection

Wagon

Model code		Engine model	Transmission model	Fuel supply system
CB1W	LNDR1D	4G13 (1,299 ml)	F5M21 (2WD-5M/T)	Variable-venturi carburettor

<Vehicles for GCC>

Hatchback

Model code		Engine model	Transmission model	Fuel supply system
CA1A	MNDLW	4G13 (1,299 ml)	F5M21 (2WD-5M/T)	Variable-venturi carburettor
CA2A	MNJLW	4G15 (1,468 ml)		
	MKJLW		F3A21 (2WD-3A/T)	
CA5A	MNGMLW	4G93 (1,834 ml)	F5M22 (2WD-5M/T)	MPI

Sedan

Model code		Engine model	Transmission model	Fuel supply system
CB1A	SNMLW	4G13 (1,299 ml)	F5M21 (2WD-5M/T)	Variable-venturi carburettor
	SNDLW			
CB2A	SNJLW	4G15 (1,468 ml)	F3A21 (2WD-3A/T)	
	SKJLW			

Wagon

Model code		Engine model	Transmission model	Fuel supply system
CB1W	LNMLW	4G13 (1,299 ml)	F5M21 (2WD-5M/T)	Variable-venturi carburettor
	LKMLW		F3A21 (2WD-3A/T)	
CB2W	LNJLW	4G15 (1,468 ml)	F5M21 (2WD-5M/T)	
	LKJLW		F3A21 (2WD-3A/T)	