

SINGLE PART INSTALLATION POSITION

CONTENTS


RELAY	3-2
CONTROL UNIT	3-2
SENSOR	3-2



RELAY



36S0262




16S0774


NOTE

For R.H. drive vehicles, part installation position are symmetrical.

CONTROL UNIT



16S0773




36S0262


NOTE

For R.H. drive vehicles, part installation position are symmetrical.

SENSOR



16S0231



16M0299