

Lubricants & Fluids

assembly	capacity (litres)	specifications	checks	renew / change	torque settings
engine sump	5,3; including filter filter: 0,8	API: at least CD above -10 °C: SAE 20W-40 above -15 °C: SAE 15W40	every time	versions with EGR: every 5.000 km / 6 months versions without EGR: every 7.500 km / 6 months	drain plug: 35 - 45 Nm
transaxle	1,8	API: GL-4, hypoid transmission oil SAE 75W-85W	every 15.000 km / 1 year	every 75.000 km / 5 years	filler and drain plugs: 30 - 35 Nm
automatic trans- mission/differential	5,8	ATF Dexron, Dexron II	every 15.000 km / 1 year	every 75.000 km / 5 years	—
cooling system	8,0	coolant; ethylene glycol based	every 30.000 km / 2 years	every 60.000 km / 4 years	—
power steering	0,9	ATF Dexron, Dexron II	every 15.000 km / 1 year	top-up only	—
brake system	0,6	SAE J1703 DOT 3, DOT 4	every 15.000 km / 1 year	every 30.000 km / 2 years	—
clutch	—	SAE J1703 DOT 3, DOT 4	every 15.000 km / 1 year	every 30.000 km / 2 years	—
fuel tank	60	diesel fuel	—	—	—