

WIRING DIAGRAMS

Fig. 1: Engine Compt, Headlights, (Grid 1-3)

1991 Mitsubishi Montero

For DIAKOM-AUTO <http://www.diakom.ru> Taganrog support@diakom.ru (8634)315187

Copyright © 1998 Mitchell Repair Information Company, LLC

Sunday, December 17, 2000 03:38PM

COMPONENT LOCATOR:

A/C RELAYS	C 12, A-B 16
A/C SYSTEM	A-C 12-15
ALTERNATOR	B-C 1-2
ALTERNATOR RELAY	C 1-2
AUTO FREE WHEELING	
HUB CONTROL UNIT	D 11
BACK DOOR LOCK SW	B 27
BACK-UP LT SW	A 26
BATTERY	A 1
BLOWER SW	A-9 12
BUZZER	E 17
CARGO LT	A 23
CLK LTR	E 11
CLOCK	E 11
COLUMN SW	A-E 19
CRUISE CONTROL SYSTEM	D-E 13-15
DEFOGGER	C-D 27
DIAG COUN	E 7
DIMMER CONTROL SW	E 8
DIR SW	A 23, C 16
DIR FLASHER	C 16
DOME LT	A 29, A 24
DOOR LOCK SYSTEM	D-E 21-23
DOOR SWS	D 17, C 23
FRONT WIPER SYSTEM	A 16-17
FUEL GAUGE UNIT	C 22
FUEL PUMP	C 4
FUSE BLOCK	C 9-10
HAZARD FLASHER	C 16
HAZARD SW	B 16
HEADLT WASHER RELAY	C-D 17
HEATER RELAY	A 12
HORN SW	E 18
IGNITION COIL	E 4
IGNITION SW	A 11
ILLUM LITS	D-E 8
INHIBITOR SW	A 8
INSTRUMENT CLUSTER	A-D 20
KEY REMINDER SW	E 17
LIGHT CONTROL RELAY	E 19
LIGHT SW	D 18
MAIN FUS LINKS	A 1-2
METER UNIT	E 20
MPI CONTROL RELAY	B 4
MPI CONTROL UNIT	A 4-7
NOISE FILTER	E 6
OVERDRIVE CONTROL RELAY	A 8
OVERDRIVE SW	A 6
PARKING BRAKE SW	A 21
POWER TRANSISTOR	D 4
POWER WINDOWS	B-E 24-26
RADIO (PARTIAL)	D-E 10
REAR BLOWER SW	D 12
REAR WIPER	D-E 16
SEAT BELT WARNING TIMER	D 18
STARTER	C 3
STOP LT SW	E 13, C 16
SUB FUS LINKS	A 3
SUNROOF	A 24-25
WIPER SW	A-B 19

