

# JACKING & HOISTING

1993 Mitsubishi Montero

1993 WHEEL ALIGNMENT  
Mitsubishi Specifications & Procedures

Montero

## JACKING & HOISTING


NOTE: Following illustrations are given to provide reference points only. Illustrations do not represent exact structure of vehicle frame, underbody or body outline.

### EMERGENCY JACKING

Points on outline of body were designated to be used specifically with vehicle jack. If using floor jack or hoist at these points, use extreme care to avoid damaging outer body shell. See Fig. 1.

### FLOOR JACK & HOIST

Following illustrations indicate points for jacking and hoisting vehicle. These points are indicated by shaded areas on frame and underbody.



90G00329

Fig. 1: Identifying Jacking & Hoisting Points  
Courtesy of Mitsubishi Motor Sales of America.