QUICK REFERENCE INDEX

Publication Number: SM7E00-1T31E0E

Dublication Numbers	Qι	JICK REFERENCE INI	JEX	
MODEL T31 SERIES	Α	GENERAL INFORMATION	GI	General Information
		ENGINE	EM	Engine Mechanical
	_		LU	Engine Lubrication System
			CO	Engine Cooling System
			EC	Engine Control System
			FL	Fuel System
			EX	Exhaust System
			STR	Starting System
			ACC	Accelerator Control System
	_	TRANSMISSION	CL	Clutch
	U	& DRIVELINE	TM	Transaxle & Transmission
			DLN	Driveline
			FAX	Front Axle
			RAX	Rear Axle
	_	SUSPENSION	_	
	-	SUSPENSION	FSU	Front Suspension
			RSU	Rear Suspension
	_	DDAVEC	WT	Road Wheels & Tires
	F	BRAKES	BR	Brake System
			PB	Parking Brake System
	_	OTTERNIA.	BRC	Brake Control System
	G	STEERING	ST	Steering System
			STC	Steering Control System
	Н	RESTRAINTS	SB	Seat Belt
			SBC	Seat Belt Control System
			SR	SRS Airbag
			SRC	SRS Airbag Control System
		VENTILATION, HEATER & AIR CONDITIONER	VTL	Ventilation System
			HA	Heater & Air Conditioning System
			HAC	Heater & Air Conditioning Control System
	J	BODY INTERIOR	INT	Interior
			IP	Instrument Panel
			SE	Seat
	K	BODY EXTERIOR, DOOR, ROOF & VEHICLE SECURITY	DLK	Door & Lock
			SEC	Security Control System
			GW	Glass & Window System
			PWC	Power Window Control System
			RF	Roof
			EXT	Exterior
	L	DRIVER CONTROLS	MIR	Mirrors
			EXL	Exterior Lighting System
			INL	Interior Lighting System
			ww	Wiper & Washer
			DEF	Defogger
			HRN	Horn
	M	ELECTRICAL & POWER CONTROL	PWO	Power Outlet
			BCS	Body Control System
			LAN	LAN System
			LNL	LAN System (LHD)
			LNR	LAN System (RHD)
			PCS	Power Control System
			CHG	Charging System
			PG	Power Supply, Ground & Circuit Elements
	N	DRIVER INFORMATION & MULTIMEDIA	MWI	Meter, Warning Lanp & Indicator
			wcs	Warning Chime System
			AV	Audio, Visual & Navigation System
	Р	MAINTENANCE	MA	Maintenance

© 2007 NISSAN EUROPE S.A.S.

All rights reserved. No part of this Electronic Service Manual may be reproduced or stored in a retrieval system, or transmitted in any form, or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of Nissan Europe S.A.S., Paris, France.

FOREWORD

This manual contains maintenance and repair procedures for the NISSAN X-TRAIL. model T31 series.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle.

The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately.

Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by NISSAN must first be completely satisfied that neither personal safety nor the vehicle's safety will be jeopardized by the service method selected.



NISSAN EUROPE S.A.S.

Service Engineering Section Paris, France