2. Schedule

A: MAINTENANCE SCHEDULE 1

1. U.S.

		MAINTENANCE INTERVAL [Number of months or km (miles), whichever occurs first]																	
	Months	3	7.5	15	22.5	30	37.5	45	52.5	60	67.5		82.5	90	97.5		112.5	120	Remarks
	× 1,000 km	4.8	12	24	36	48	60	72	81.4	96	108	120	132	144	156	168	180	192	ricinario
	× 1,000 km	3	7.5	15		30	37.5	45	52.5	60	67.5	75	82.5	90	97.5	105		120	
	miles		7.0				07.0		02.0		07.0	'	02.0		07.0	100	1 12.0		
1	Engine oil	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	
2	Engine oil filter	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	
3	Spark plugs					R				R				R				R	Non- TURBO model
										R									TURBO model
4	Drive belt(s)					ı				ı				ı		R			model
5	Camshaft Drive belt					I				I				I		R			
6	Fuel line					(I)				(I)				(I)				ı	Note (1)
7	Fuel filter									(R)								R	Note (1)
8	Air cleaner element					R				R				R				R	Note (2)
9	Cooling system					I				I				I				I	
10	Coolant					R				R				R				R	
11	Clutch sys- tem			-		I		_		I		I		_		I		I	
12	Transmis- sion oil					I				I				I				I	
13	ATF					I				I				I				I	Note (3)
14	Front & rear differential oil					I				I				I				I	
15	Brake line			I		I		I		I		I		I		I		I	
16	Brake fluid					R				R				R				R	
17	Disc brake pads & discs					I				ı				I				I	
18	Parking brake			I		I		I		I		I		I		I		I	
19	Suspension			I		ı		I		I		I		ı		I		I	
20	Wheel bear- ing									(I)								(I)	
21	Axle boots & joints			I		I		I		I		I		I		I		I	
22	Tire rotation		ı	ı	I	ı	ı	I	I	ı	Ι	I	I	ı	I	I	I	ı	Note (4)
23	Steering system (Power steering)			I		I		I		I		I		ı		I		I	

SCHEDULE

PERIODIC MAINTENANCE SERVICES

		MAINTENANCE INTERVAL [Number of months or km (miles), whichever occurs first]								
	Supple- ment restraint system	Inspect every 10 years.								
25	A/C filter	Replace every 12 months or 15,000 km (9,300 miles).	Note (5)							

Symbols used:

R: Replace

I: Inspection

(R) or (I): Recommended service for safe vehicle operation.

NOTE

- (1) This inspection is not required to maintain emission warranty eligibility and it does not affect the manufacturer's obligations under EPA's in-use compliance program.
- (2) When the vehicle is used in extremely dusty conditions, the air cleaner element should be replaced more often.
- (3) ATF filter is maintenance free part. ATF filter needs replacement, when it has physically damaged or ATF leaked.
- (4) A tire should be replaced when the tread wear indicator appears as a solid band across the tread. The indicators appear when the remaining tread has been worn to 1.6 mm (0.063 in) or less.
- (5) If A/C filter equipped.

2. CANADA

		MAINTENANCE INTERVAL																	
	Months	[Number of months or km (miles), whichever occurs first] 3 7.5 15 22.5 30 37.5 45 52.5 60 67.5 75 82.5 90 97.5 105 112.5 120									Remarks								
		4.8					60	72	5≥.5 81.4	96	108	120	132	144	156	168	180		Remarks
	× 1,000 km		12	24	36	48												192	
	× 1,000 miles	3	7.5	15	22.5	30	37.5	45	52.5	60	67.5	75	82.5	90	97.5	105	112.5	120	
1	Engine oil		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	
2	Engine oil filter		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	
3	Spark plugs					R				R				R				R	Non- TURBO model
										R									TURBO model
4	Drive belt(s)					ı				I				I		R			
5	Camshaft Drive belt					I				I				I		R			
6	Fuel line					(I)				(I)				(I)				I	Note (1)
7	Fuel filter					\-7				(R)				\-				R	Note (1)
8	Air cleaner element					R				R				R				R	Note (2)
9	Cooling sys- tem					I				I				I				I	
10	Coolant					R				R				R				R	
11	Clutch sys- tem			I		I		I		I		I		I		I		I	
12	Transmis- sion oil					I				I				I				I	
13	ATF					ı				ı				ı				I	Note (3)
14	Front & rear differential oil					I				I				I				I	
15	Brake line			I		ı		I		ı		I		I		I		I	
16	Brake fluid					R				R				R				R	
17	Disc brake pads & discs					I				I				I				I	
18	Parking brake			I		I		I		I		I		I		I		I	
19	Suspension			I		I		I		I		I		I		I		I	
20	Wheel bear-ing									(I)								(I)	
21	Axle boots & joints			I		I		I		I		I		I		I		I	
22	Tire rotation		ı	I	I	ı	I	I	I	ı	ı	I	I	I	I	I	I	I	Note (4)
23	Steering system (Power steering)			I		I		I		I		I		I		I		I	
24	Supple- ment	Inspect every 10 years.																	
	restraint system																		
25	75 A/C filter Replace every 12 months or 15,000 km (9,300 miles).										Note (5)								

SCHEDULE

PERIODIC MAINTENANCE SERVICES

Symbols used:

- R: Replace
- I: Inspection
- (R) or (I): Recommended service for safe vehicle operation.

NOTE

- (1) This inspection is not required to maintain emission warranty eligibility and it does not affect the manufacturer's obligations under EPA's in-use compliance program.
- (2) When the vehicle is used in extremely dusty conditions, the air cleaner element should be replaced more often.
- (3) ATF filter is maintenance free part. ATF filter needs replacement, when it has physically damaged or ATF leaked.
- (4) A tire should be replaced when the tread wear indicator appears as a solid band across the tread. The indicators appear when the remaining tread has been worn to 1.6 mm (0.063 in) or less.
- (5) If A/C filter equipped.

B: MAINTENANCE SCHEDULE 2

Item	Every	Repeat short distance drive	Repeat rough/muddy road drive	Extremely cold weather area	Salt or other corrosive used or coastal area	High humid- ity or moun- tain area	Repeat tow- ing trailer
Engine oil	3.75 months	R		R			R
	6,000 km						
	3,750 miles						
Engine oil filter	3.75 months	R		R			R
	6,000 km						
	3,750 miles						
Fuel filter	15 months						
	24,000 km						
	15,000 miles						
Fuel line	15 months				I		
	24,000 km	1					
	15,000 miles	-					
Transmission oil	15 months						R
	24,000 km	=					
	15,000 miles	=					
ATF	15 months						R
	24,000 km						
	15,000 miles	1					
Front & rear differ-	15 months						R
ential oil	24,000 km						
	15,000 miles	1					
Brake line	15 months	1	ı		I		I
	24,000 km	1					
	15,000 miles	-					
Brake fluid	15 months					R	
Drano mara	24,000 km	-					
	15,000 miles						
Disc brake pads &	15 months	1	1		ı		1
discs	24,000 km	•					
	15,000 miles						
Parking brake	15 months	ı	1		ı		1
Tarking brake	24,000 km	· '	'				'
	15,000 miles	1					
Suspension	7.5 months			1	ı		ı
Ouspension	12,000 km	-	'	'	'		'
	7,500 miles	-					
Axle boots & joints	7.5 months		1	1	ı		l
AND DUDIS & JUITIES	12,000 km	- '	'	'	'		'
	<u> </u>	-					
Steering system	7,500 miles 7.5 months	1	1	1	1		1
(Power steering)		I	'	'			'
(1 Ower steering)	12,000 km	4					
	7,500 miles						