

# DATA LINK CONNECTOR

ENGINE (DIAGNOSTICS)

## 7. Data Link Connector


### A: NOTE

This connector is used both for the general scan tools and Subaru Select Monitor.

### CAUTION:

**Do not connect any scan tools other than the general scan tools and Subaru Select Monitor,**

**because the circuit for Subaru Select Monitor may be damaged.**



Terminal No.	Contents	Terminal No.	Contents
1	Power supply	9	Blank
2	Blank	10	Subaru Select Monitor/General scan tool signal
3	Blank	11	Blank
4	Blank	12	Ground
5	Blank	13	Ground
6	Line end check signal 1	14	Blank
7	Blank	15	Blank
8	Line end check signal 2	16	Blank